

30.4 Using FlexNetwork External I/O


30.4.1 Detail

By connecting the FLEX NETWORK unit to the GP, you can use the display unit to control remotely located external I/O, in addition to controlling other things besides inputs and outputs. You can also add multiple FLEX NETWORK units to increase the number of I/O points.

There are two connection lines for the unit and the same communication data is output to both.

When you use either line both line 1 and line 2 are available. When you are using one line, the maximum number of stations you can connect is 31. When you are using two lines, the maximum number of stations you can connect is 63. One line will support 31 and the other line will support 32.

For details on configuration, refer to Section 1.1 System Configurations in the "FLEX NETWORK Users Manual".



NOTE

- A proprietary cable is needed to connect the FLEX NETWORK unit to the GP.

■ FLEX NETWORK Units: Models and Number of Stations


The following describes the type, number of points, and number of stations for FLEX NETWORK units.

For example, if you use an I/O unit with 32 discrete inputs and 32 discrete outputs for a total of 64 points, and define S-Number 1, then the I/O unit will use S-Number 1 to 4.

Type		Type	Number of Points	Number of Occupied Stations
IO		FN-X16TS	16 input points	1 station
		FN-X32TS	32 input points	2 stations
		FN-Y08RL	8 output points	1 station
		FN-Y16SK	16 output points	1 station
		FN-Y16SC	16 output points	1 station
		FN-XY08TS	8 input points 8 output points	1 station
		FN-XY16SK	16 input points 16 output points	1 station
		FN-XY16SC	16 input points 16 output points	1 station
		FN-XY32SK	32 input points 32 output points	4 stations
Analog		FN-AD02AH	2chA/D	1 station
		FN-AD04AH	4chA/D	4 stations
		FN-DA02AH	2chD/A	1 station
		FN-DA04AH	4chD/A	4 stations
Special	Positioning	FN-PC10SK	-	4 stations
	High Speed Counter	FN-HC10SK41	-	8 stations


30.4.2 Procedure

NOTE

- Please refer to the Settings Guide for details.
 "30.3.3 [I/O Driver Settings] Setting Guide" (page 30-12)


The following is an example of how to use digital I/O (DIO) in the FLEX NETWORK unit.

- 1 Select AGP-XXXXX-FN1M as the display unit. The FLEX NETWORK driver is automatically set up.
- 2 In the [System Settings] window, select [I/O Driver] to display the following screen.



NOTE

- If the [System Settings] tab is not displayed in the workspace, on the [View (V)] menu, point to [Workspace (W)], and then click [System Settings (S)].


- 3 Click [I/O Driver Settings]. In the dialog box that appears, select the Transmission Speed and click [OK].



4 In the I/O Driver window, select the I/O unit to be configured, and click [Setting].




5 The [Unit Settings] dialog box appears. To change the type, in the [Model] area, select the model of I/O unit. (For example, [Input and Output] and "FN-XY16SK").



NOTE


- When using an analog unit, set the Type to [Analog]. When using positioning units or a high-speed counter, set the Type to [Special].

6 Specify the same number as the S-Number specified on the unit.




- NOTE**
- You can specify the S-No from 1 to 63. However, you cannot duplicate the same S-No in the same FLEX NETWORK.
 - " ■ FLEX NETWORK Units: Models and Number of Stations" (page 30-14)
 - To define detailed settings in the I/O unit, click [Details], make your changes, and click [OK]. The positioning unit does not have detail settings.

7 In the [Unit Settings] dialog box, click [OK] to apply the changed settings.



8 To add I/O units, click [Add]. In the [Unit Settings] dialog box, follow the procedure similar to steps 5 to 7 to complete the setup. You can add different types of units.

9 After completing the device settings for the FLEX NETWORK, map the addresses to the I/O terminals.
Click [I/O Screen] to set up I/O terminals.



- NOTE**
- You can also display the I/O Screen from the [Screen List] window.

10 Map an address (variable) to each terminal. The following describes how to map addresses.
"30.1.2 Mapping Addresses (variables) to I/O Terminals" (page 30-3)

30.4.3 I/O Terminal Operations

An I/O terminal to which an address is mapped operates as described below.

◆ Input and output (DIO)

- When the input terminal turns ON, the address mapped to the terminal turns ON.
- When the address mapped to the output terminal turns ON, the terminal turns on.
- If a power interruption occurs on the I/O unit, the driver can recognize it and resume communications after the power resumes.

◆ Analog unit

- The A/D conversion unit converts an analog input value to a digital value.
- In the opposite way, the D/A conversion unit converts a digital input value to an analog value.
- For details, refer to "Flex Network Analog Unit User Manual, 2.3 Analog Characteristics".
- For details on how to acquire data values according to the filter type, refer to "Flex Network Analog Unit User Manual, 2.4 Analog/Digital Conversion".
- If a power interruption occurs on the I/O unit, the driver can recognize it and resume communications after the power is resumed.

◆ Positioning unit


- Specifies the data value by reading or writing by a command, and determines the position.
- For details on commands, refer to the "Single-Axis Positioning Unit User Manual", sections titled "FlexNetwork Driver Settings" and "RUN Data".
- If a power interruption occurs on the I/O unit, the driver can recognize it and resume communications after the power is resumed.


◆ High-Speed Counter Unit

- Specifies the data value by reading or writing by a command, and operates the counter.
- For details on commands, refer to "High-Speed Counter Unit Users Manual 5.1 FLEX NETWORK Driver Settings" and "High-Speed Counter Unit Users Manual 5.2 Data Settings".
- If a power interruption occurs on the I/O unit, the driver can recognize it and resume communications after the power is resumed.


30.4.4 [I/O Driver] Settings Guide

When using the AGP-XXXXX-FN1M display unit, in the System Settings window click [I/O Driver] to display the following window.




Setting	Description
I/O Driver Settings	This button displays the [I/O Driver Settings] dialog box. 
Communication Speed	Select the communication speed for FLEX NETWORK as either [6Mbps] or [12Mbps].
Add	Adds I/O units.
Settings	Click the button. The [Unit Settings] dialog box appears. Use the dialog box to select your I/O unit and define I/O details. ☞ " ◆ Unit Settings" (page 30-20)
Delete	Deletes I/O units.
I/O Screen	Click the button to switch to the I/O screen.

◆ Unit Settings



Setting	Description
Type	Select the type of unit from the following options. Only relevant type models are displayed. All : Displays all units. Input : Displays units with inputs only. Output : Displays units with outputs only. I/O : Displays units with both inputs and outputs. Analog : Displays analog units. Special : Displays special units other than the above.
Information	Displays details for the I/O unit settings.
S-Number	Specify a number (S-Number) to identify the I/O unit connected to the FLEX NETWORK. The settings range from 1 (default) to 63.
Details	This button displays the [Details] dialog box for the selected I/O unit.


◆ Setting Details for DIO Units




32 input and output points (FN-XY32SK)

Setting	Description
Input	Select the variable type for the input from either [Bit] or [Word]. The 8, 16, or 32 points change depending on the type of I/O unit.
Output	Select the variable type for the output from either [Bit] or [Word]. The 8, 16, or 32 points change depending on the type of I/O unit.


◆ Setting Details for Analog Units



2chA/D
(FN-AD02AH)



4chA/D
(FN-AD04AH)




2chD/A
(FN-DA02AH)

Setting	Description
Number of Channels to be Used	Select [2CH] or [1CH] in the 2-channel analog unit.
Range	<p>Set the range (resolution) in the 2-channel analog unit.</p> <p>0-10V : 0 - 4095 0-20mA : 0 - 4095 4-20mA : 0 - 4095</p> <ul style="list-style-type: none"> The range (resolution) of the 4-channel analog unit is set in the display unit. <p>0-5V : 0 - 4095 1-5V : 0 - 4095 0-10V : 0 - 4095 -5-5V : -2047 - 2047 -10-10V: -2047 - 2047 0-20mA: 0 - 4095 4-20mA: 0 - 4095</p>

Continued

Setting	Description
Type	Select the filter type. 2-channel analog: None, Moving Average 4-channel analog: None, Average, Moving Average For details on filter, refer to Section 2.4 Analog/Digital Conversion, in the "Flex Network Analog Unit User Manual".
Sampling Frequency	Select the number of samples for A/D conversion. When the filter type is set to [None], this option can be selected. 2-channel analog: 2/4/8/16/32/64 4-channel analog: 2/4/8/16/32/64/128/256/512/1024/2048/4096/ 8192/16384/32768/65536
Drop high/low	Specify whether to remove the maximum and minimum values in the sample data. This option can be selected if the number of samples for A/D conversion is set to 4 or higher. If the number of samples is fewer than 4, this option cannot be selected.

◆ Setting Details for High-Speed Counters



(FN-HC10SK)

Setting	Description
Type	Select [16-bit UpCounter x 2CH], [32-bit UpCounter], or [32-bit UpDownCounter].
Measurement rate (pps)	Select the measurement speed. <ul style="list-style-type: none"> • When setting [Type] to [16-bit UpCounter x 2CH] or [32-bit UpCounter], select [1K] or [10K]. • When setting [Type] to [32-Bit UpDownCounter], select [Line Driver] or [Open Collector].
Pulse Counter	Select the pulse count method from [1 Signal - Multiply by 1 (50kpps)], [1 Signal - Multiply by 1 (200kpps)], [2 Signal - Multiply by 1 (50kpps)], [2 Signal - Multiply by 1 (200kpps)], [2 Signal - Multiply by 2 (25kpps)], [2 Signal - Multiply by 2 (100kpps)], [2 Signal - Multiply by 4 (12.5kpps)], or [2 Signal - Multiply by 4 (50kpps)].
Counter format	Select [Linear], [Ring], or [Frequency]. For details on the count method, refer to Section 4.2 Various Functions, in the "High-Speed Counter Unit User Manual".