

Mitsubishi Electric

Melsec-A CPU (SIO) Driver

- 1 System Structure
- 2 Cable Diagrams
- 3 Supported Device Addresses
- 4 Consecutive Device Addresses
- 5 Environment Setup
- 6 I/O Manager Configuration
- 7 Driver Configuration
- 8 Protocol Configuration
- 9 Device Address Configuration

- This manual explains how to connect the target machine with other manufacturer devices. For information about how to use the Pro-Designer software, please refer to the Pro-Designer Online Help.
- The types of target machines that are compatible with Pro-Designer depends on the version of Pro-Designer. For information about the compatibility of target machines, please refer to the Pro-Designer Online Help.

1 System Structure

The following table describes the basic system setup for connecting the target machine to Mitsubishi Melsec-A Series PLCs.

To view a cable connection diagram for a particular communication format, see Section 2 – *Cable Diagrams*.

Series	CPU ^{*1}	Link I/F	Comm. Format	Diagram
Melsec-A Series	A2A	CPU Direct	RS-232C	Cable Diagram 1
	A3A			
	A1N			
	A2N			
	A3N			
	A1SJ			
	A1SJH			
	A1SH			
	A2SH			
	A2U			
	A3U			
	A2U	2 Port Adapter II (Pro-face: GP070-MD11)	RS-422(4-wire)	Cable Diagram 3
	A3U			
	A2U-S1			
	A2US			
A2USH-S1				

*1 Connected to Programming Console interface.

2 Cable Diagrams


The illustrated cable diagrams and those recommended by Mitsubishi may differ. However, Pro-face recommends using the following diagrammed connections.

Ground the PLC's FG terminal according to your country's applicable standard. For details, refer to the PLC manual.

Diagram 1 RS-232C

To connect the target machine and the PLC, use the recommended cable.

Target Machine	Cable/Adapter	Note
GP, PS-P, PC/AT(PL), PS-G	RS-232C Cable (Data Link: RSCV-MF(25-pin) or Diatrend: DAFXIH-CAB(25-pin), DAFXIH-CAB(9-pin))	Be sure the cable used/selected fits the target unit's serial I/F connector. Cable length: 15m max.



Cable Diagram 2 RS-422

To connect the target machine and the PLC, use a recommended cable or create your own cable using the following specifications.

Target Machine	Cable / Adapter	Note
GP*1, PS-P*1	User-created Cable	Cable length: 15m max.

*1 Connect to COM1.





Diagram 3 RS-422 (4-wire)

To connect the target machines and the PLC, use the recommended cable (and a pin adapter if necessary).

Target Machine	Cable/Adapter	Note
GP* ¹ , PS-P* ¹	a 2Port Adapter II and RS-422 Cable (Pro-face: GP070-MDCB11)	Cable Length: 500m max.
	b 2Port Adapter II and User-created Cable ^{**2}	
PC/AT(PL), PS-G	b 2Port Adapter II, User-created Cable ^{**2} and RS-232C/RS422(485) adapter	


*1 Only COM1 can be used.

- a. When use the 2Port Adapter II and RS-422 Cable(GP070-MDCB11).



- b. When use the 2Port Adapter II and User-created Cable.

When use the 2Port Adapter II, User-created Cable, and RS-232C/RS-422(485) adapter.

**MEMO**

When creating your own cable, refer to the Mitsubishi Melsec 2 Port Adapter II Manual for cable connections.

3 Supported Device Addresses

The following table lists the device address ranges you can enter from the [Device Address keypad](#).

For actual device address ranges supported by the PLC, refer to the corresponding PLC manual. Supported device addresses differ from protocol to protocol and between PLC models.

3.1 AnA Series

Device	Bit Address	Word Address	16 bit	32 bit
Input Relay	X0000-X1FFF	X0000-X1FF0 ^{*1}	LH ^{*6}	LH ^{*6}
Output Relay	Y0000-Y1FFF	Y0000-Y1FF0 ^{*1}		
Internal Relay	M0000-M8191	M0000-M8176 ^{*2}		
Latch Relay	L0000-L8191	L0000-L8176 ^{*2}		
Special Relay	M9000-M9255	M9000-M9240 ^{*2}		
Annunciator	F0000-F2047	F0000-F2032 ^{*2}		
Link Relay	B0000-B0FFF	--		
Timer (contact)	TS0000-TS2047	--		
Timer (coil)	TC0000-TC2047	--		
Counter (contact)	CS0000-CS1023	--		
Counter (coil)	CC0000-CC1023	--		
Timer (current value)	--	TN0000-TN2047		
Counter (current value)	--	CN0000-CN1023		
Data Register ^{*3}	D0000:0-D8191:15	D0000-D8191 ^{*4}		
Special Register ^{*3}	D9000:0-D9255:15	D9000-D9255 ^{*4}		
Link Register ^{*3}	W0000:0-W1FFF:F	W0000-W1FFF ^{*5}		
File Register ^{*3}	R0000:0-R8191:15	R0000-R8191 ^{*4}		

*1 To use as word address, the bit number (last digit) must be 0.

*2 To use as word address, must be multiple of 16.

*3 When the bit write operation is performed, the Target Machine reads the PLC's corresponding word address and turns a bit ON, then send back to PLC. Do not write to the word address from the ladder program in the middle of this operation.

*4 You can define a bit address by adding a colon followed by the bit position (0-15) at the end of the word. (e.g. D0100:8)

*5 You can define a bit address by adding a colon followed by the bit position (0-F) at the end of the word. (e.g. W0001:A)

*6 16-bit and 32-bit data, High and Low, refer to data as defined in the following examples.

Byte	16 bit	Word	32 bit
0	7 ... 0	0	15 ... 0
1	15 ... 8	1	31 ... 16
	L (Low)		L (Low)
	H (High)		H (High)

3.2 AnN Series

Device	Bit Address	Word Address	16 bit	32 bit
Input Relay	X0000-X07FF	X0000-X07F0 ^{*1}	LH ^{*6}	LH ^{*6}
Output Relay	Y0000-Y07FF	Y0000-Y07F0 ^{*1}		
Internal Relay	M0000-M2047	M0000-M2032 ^{*2}		
Latch Relay	L0000-L2047	L0000-L2032 ^{*2}		
Special Relay	M9000-M9255	M9000-M9240 ^{*2}		
Annunciator	F000-F255	F000-F240 ^{*2}		
Link Relay	B0000-B03FF	--		
Timer (contact)	TS000-TS255	--		
Timer (coil)	TC000-TC255	--		
Counter (contact)	CS000-CS255	--		
Counter (coil)	CC000-CC255	--		
Timer (current value)	--	TN000-TN255		
Counter (current value)	--	CN000-CN255		
Data Register ^{*3}	D0000:0-D1023:15	D0000-D1023 ^{*4}		
Link Register ^{*3}	W0000:0-W03FF:F	W0000-W03FF ^{*5}		
File Register ^{*3}	R0000:0-R8191:15	R0000-R8191 ^{*4}		

*1 To use as word address, the bit column (last column) must be 0.

*2 To use as word address, must be multiple of 16.

*3 When the bit write operation is performed, the Target Machine reads the PLC's corresponding word address and turns a bit ON, then send back to PLC. Do not write to the word address from the ladder program in the middle of this operation.

*4 You can define a bit address by adding a colon followed by the bit position (0~15) at the end of the word. (e.g. D0100:8)

*5 You can define a bit address by adding a colon followed by the bit position (0~F) at the end of the word. (e.g. W0001:A)

*6 16-bit and 32-bit data, High and Low, refer to data as defined in the following examples.

Byte	16 bit			Word	32 bit				
0	7	...	0	L (Low)	0	15	...	0	L (Low)
1	15	...	8	H (High)	1	31	...	16	H (High)

3.3 AnU Series

Device	Bit Address	Word Address	16 bit	32 bit
Input Relay	X0000-X1FFF	X0000-X1FF0 ^{*1}	LH ^{*6}	LH ^{*6}
Output Relay	Y0000-Y1FFF	Y0000-Y1FF0 ^{*1}		
Internal Relay	M0000-M8191	M0000-M8176 ^{*2}		
Latch Relay	L0000-L8191	L0000-L8176 ^{*2}		
Special Relay	M9000-M9255	M9000-M9240 ^{*2}		
Annunciator	F0000-F2047	F0000-F2032 ^{*2}		
Link Relay	B0000-B1FFF	--		
Timer (contact)	TS0000-TS2047	--		
Timer (coil)	TC0000-TC2047	--		
Counter (contact)	CS0000-CS1023	--		
Counter (coil)	CC0000-CC1023	--		
Timer (current value)	--	TN0000-TN2047		
Counter (current value)	--	CN0000-CN1023		
Data Register ^{*3}	D0000:0-D8191:15	D0000-D8191 ^{*4}		
Special Register ^{*3}	D9000:0-D9255:15	D9000-D9255 ^{*4}		
Link Register ^{*3}	W0000:0-W1FFF:F	W0000-W1FFF ^{*5}		
File Register ^{*3}	R0000:0-R8191:15	R0000-R8191 ^{*4}		

- *1 To use as word address, the bit column (last column) must be 0.
- *2 To use as word address, must be multiple of 16.
- *3 When the bit write operation is performed, the Target Machine reads the PLC's corresponding word address and turns a bit ON, then send back to PLC. Do not write to the word address from the ladder program in the middle of this operation.
- *4 You can define a bit address by adding a colon followed by the bit position (0-15) at the end of the word. (e.g. D0100:8)
- *5 You can define a bit address by adding a colon followed by the bit position (0-F) at the end of the word. (e.g. W0001:A)
- *6 16-bit and 32-bit data, High and Low, refer to data as defined in the following examples.

	16 bit					32 bit			
Byte					Word				
0	7	...	0	L (Low)	0	15	...	0	L (Low)
1	15	...	8	H (High)	1	31	...	16	H (High)

4 Consecutive Device Addresses

The following table lists the maximum number of consecutive addresses that can be read by each PLC. Refer to this table when using block transfers.

MEMO

- To speed up data communication, use consecutive device addresses on the same panel screen.
- The following situations increase the number of times that the device is read, and reduces the data communication speed between the target machine and the PLC:
 - when the number of consecutive addresses exceeds the maximum
 - when an address is designated for division
 - when different device types are used

4.1 AnA, AnU Series

Device	Max. Consecutive Addresses	Gap Span
Input Relay (X)	256 bits	47 bits
Output Relay (Y)		
Internal Relay (M)		
Latch Relay (L)		
Special Relay (M)		
Annunciator (F)		
Link Relay (B)		
Timer [contact] (TS)		
Timer [coil] (TC)		
Counter [contact] (CS)		
Counter [coil] (CC)		
Data Register (D)		
Link Register (W)		
File Register (R)		
Special Register (D)		
Timer [current value] (TN)		
Counter [current value] (CN)		

4.2 AnN Series

Device	Max. Consecutive Addresses	Gap Span
Input Relay (X)	32 bits	31 bits
Output Relay (Y)		
Internal Relay (M)		
Latch Relay (L)		
Special Relay (M)		
Annunciator (F)		
Link Relay (B)		
Timer [contact] (TS)		
Timer [coil] (TC)		
Counter [contact] (CS)		
Counter [coil] (CC)		
Data Register (D)		
Link Register (W)		
File Register (R)		
Timer [current value] (TN)		
Counter [current value] (CN)		

5 Environment Setup

The following table lists the communication settings, recommended by Pro-face, for the target machine and Mitsubishi Melsec PLCs.

For details, see Section 7 – *Driver Configuration*, and Section 8 – *Protocol Configuration*.

RS-232C

Target Machine Settings			PLC Settings
Driver	Serial Interface	RS-232C	--
	Flow Control	None	--
	Transmission Speed	9600 bps	--
	Retry Count	2	--
	Parity Bit	Odd	--
	Stop Bit	1 bit	--
	Data Length	8 bit	--
	Rcv Time Out	10 s	--
	TX Wait Time	0 ms	--

RS-422 (4-wire)

Target Machine				PLC Settings
	GP, PS-P	PC/AT(PL), PS-G		
Driver	Serial Interface	RS-422(4 Wire)	RS-232C ^{*1}	--
	Flow Control	None		--
	Transmission Speed	9600 bps		--
	Retry Count	2		--
	Parity Bit	Odd		--
	Stop Bit	1 bit		--
	Data Length	8 bits		--
	Rcv Timeout	10 sec		--
	TX Wait Time	0 msec		--

*1 By using a RS-232C/RS-422(485) signal converter, you can use RS-422 connections with PC/AT (PL Series) and PS Series Type G target machines. In such a configuration, make sure you set the Driver's Serial Interface to RS-232C.

MEMO


The PLC program cycle time slows by approximately 8% when you connect the target machine to the programming port.

6 I/O Manager Configuration

The driver and protocol, which enable communication between the target machine and the PLC, depends on the PLC type.

MEMO

For information on how to display the [New Driver Interface] dialog box, see the online help.



7 Driver Configuration

To configure the communication settings of the serial driver in the target machine, use the [Driver Configuration] dialog box. Make sure the settings match those of the PLC.

For an overview of the driver and protocol settings, see Section 5 – *Environment Setup*.

MEMO

For information on how to display the [Driver Configuration] dialog box, see the online help.

Manufacturer

Displays the name of the PLC manufacturer.

Interface

Displays the type of serial connection used to connect the target machine to the PLC.

COM Port

Defines which COM port to use on the target machine, for connecting to the PLC.

MEMO

Select COM1 for PS Series Type G target machines. Connection is not possible using COM2.

Serial Interface

Defines the serial connection: RS-232C or RS-422 (4-wire).

For details about the supported connections, see Section 2 – *Cable Diagrams*.

Flow Control

Defines the signals that control the data flow.

Transmission Speed

Sets the communication speed in bits per second. This setting must match the PLC baud rate.

Retry Count

Defines the number of times the driver tries to send or receive data when there is an error.

Parity Bit

Sets either a parity bit [Even or Odd] for use in detecting communication errors, or [None] at all.

Stop Bit

Defines the stop bit: 1, 1.5, or 2 bits.

Data Length

Defines the length of each unit of data: 7 bit or 8 bit.

Rcv. Timeout

Defines the length of time the target machine waits for a response before it outputs a timeout error or sends another communication.

TX Wait Time

Defines the number of milliseconds that the target machine waits, after receiving a communication packet, before sending a response.


8 Protocol Configuration

To set up details about the communication process between the target machine and the PLC, use the [Protocol Configuration] dialog box.

For an overview of the driver and protocol settings, see Section 5 – *Environment Setup*.

MEMO

For information on how to display the [Protocol Configuration] dialog box, see the online help.



2Port Adapter

Select when connecting the 2Port Adapter II to the CPU programming port. The 2Port Adapter II enables one RS-422 and one RS-232C connection.

When using the 2Port Adapter II, monitor commands are disabled.

9 Device Address Configuration

To set up a PLC variable in the Variable List, use the Device Address Keypad from the variable properties.

See Section 3 – *Supported Device Addresses*.

MEMO

For information on how to display the Device Address Keypad, see the online help.



Device

Lists the PLC's discrete and word device types.

Address

Enter the device address for the PLC variable. The keypad ensures that you enter the correct format for bit and word devices.