

# INDEX

<b>A</b>	
ACTION-Specific Trigger Condition/Process List.....	32-56
Add Node	
GP Series Node .....	30-40
GP3000 Series Node .....	30-32
Pro-Server EX Node.....	30-30
WinGP Node .....	30-36
API Functions.....	26-2
Array of Symbols .....	28-15
Automatic Download of GP Filing Data.....	17-7
Automatic Upload of GP Filing Data.....	16-7
<b>C</b>	
Create form using Excel.....	5-9, 6-8, 6-39, 9-7, 11-9, 11-37
Create Histogram.....	5-75
Create Pareto Graph .....	5-73
Create Scatter Graph .....	5-74
<b>D</b>	
Data Read Performance Measurement.....	28-5
Data settings to be received by ACTION.....	32-32
Data Transfer.....	25-2
Data Transfer (Collection Type).....	18-43
Data Transfer (Distribute Type).....	18-35
Device Access Log.....	28-36
Device Backup .....	20-6
Device Logging.....	5-41
Device Monitor .....	27-16
Device OneShot.....	6-62
Device Restore .....	21-4
Download from the database.....	13-11
A setup of details.....	13-27
<b>E</b>	
Edit Symbol.....	31-42
Excel Operation Function.....	5-68
Export Nodes and Symbols.....	24-7
<b>F</b>	
Factory Gateway Configuration Tool .....	23-11
<b>G</b>	
Global Constant Setting .....	31-45
GP Capture Data Saving .....	10-25
Grouping .....	28-7
<b>I</b>	
Import Device Cache Buffer.....	28-30
Import Nodes and Symbols .....	24-7
<b>L</b>	
Log Data Upload.....	9-26
Log Viewer .....	27-32
<b>N</b>	
Network Settings .....	33-4
GP Series Node Settings.....	33-6
Pro-Server EX / GP3000 Series / WinGP node Settings.....	33-8
<b>O</b>	
Open Network Project File .....	3-6
<b>P</b>	
Printout .....	34-2
Pro-Server EX Environmental Settings.....	33-2
<b>Q</b>	
QC Chart.....	5-72
<b>R</b>	
Recipe .....	11-58
Remote Logoff.....	22-5
Remote logon.....	22-3
<b>S</b>	
Sample Wizard.....	3-8
Save Network Project .....	22-11, 22-14
Save SRAM Data Backup.....	19-6
Sequence Diagram by Trigger Condition .....	32-47
Set Password.....	22-8, 22-13, 24-6
Setting of symbol monitor .....	27-25
Start Application.....	15-8
Status Monitor .....	27-3, 27-9
Symbol Monitor.....	27-19, 27-24
Symbol Registration Screen .....	31-40

---

## T

### Trigger Condition

At Device Change .....	32-9
At Device OFF .....	32-17
At Device On.....	32-15
Constant Cycle .....	32-8
ON Time.....	32-7
Power ON .....	32-6
When conditional expression satisfied (excluding the case that the node is GP Series).....	32-21
When partner node turned Off (excluding the case that the node is GP Series) .....	32-24
Set Trigger Condition Details.....	32-25
When partner node turned On (excluding the case that the node is GP Series) .....	32-23
While conditional expression satisfied (excluding the case that the node is GP Series).....	32-19
While Device OFF.....	32-13
While Device On .....	32-11

## U

Upload of GP JPEG Data.....	10-7
Upload to the database .....	8-10
A setup of details.....	8-26

## W

Writes Data from CSV file.....	12-9
Writes Data to CSV file .....	7-8
Writes Data to E-Mail .....	14-9